


高位安裝圖示 High-level Installation Demonstration



低位安裝圖示 Low-level Installation Demonstration



型號 Model	類型 Category	安裝位置 Installation Position	外型尺寸 Dimensions	用氣量 Gas Consumption		熱水供應量 Hot Water Supply	熱水爐管道接駁 Water Heater Pipe Connection	
			高 x 闊 x 深 H x W x D	兆焦耳 / 小時 (千瓦) MJ / hr (kW)		25°C 升溫 25°C Temp. Rise	煤氣 Gas	冷/ 熱水 Cold / Hot Water
			毫米 mm 吋 inch	最高 Maximum	最低 Minimum	公升/ 分鐘 Litre / Min		(熱水循環) ⁺ (Circulation) ⁺
RJW15SN (WM)	超薄型煤氣恆溫熱水爐 Temperature-modulated Superslim Water Heater	低位 Low-level	405 x 350 x 75 15.9 x 13.8 x 3.0	125.6 (34.9)	13.7 (3.8)	16	M28 x 1.5	1/2" B.S.P
RJW20SN (WM)				161.3 (44.8)		20		
RBOX16L	箱式煤氣恆溫熱水爐 Box Type Temperature-modulated Water Heater	高位 High-level	231 x 527 x 403 9.1 x 20.7 x 15.9	123.5 (34.3)	16.2 (4.5)	15.5	3/4" B.S.P	3/4" B.S.P (1/2" B.S.P) ⁺
RBOX16QL								
RBOX16R								
RBOX16QR								
TRJW162TFL		低位 / 高位 Low-level / High-level	370 x 453 x 280 14.6 x 17.8 x 11.0	141.5 (39.3)	15.8 (4.4)	18		
TRJW162TFQL					9.0 (2.5)			
TRJW222TFL				172.8 (48.0)	15.8 (4.4)	22		
TRJW222TFQL					9.0 (2.5)			
TNJW161TFL			360 x 480 x 265 14.2 x 18.9 x 10.4	141.5 (39.3)	24.3 (6.74)	18		
TNJW161TFQL								
TNJW221TFL				171.7 (47.7)		22		
TNJW221TFQL								

+只適用於TFQL/QL/QR型號。For TFQL/QL/QR models only.
所有型號使用交流電220伏特(50赫)及採用機動排煙密封式設計。a.c. 220V (50Hz) and fan assisted room-sealed design apply to all models.

免費永久保養(首3年包零件)^
Free permanent warranty (First 3-year
includes parts warranty)*

免息分期10個月
10-month interest-free instalments

免費送貨服務^
Free delivery service^

免費標準安裝及回收舊爐^
Free standard installation and collection
of existing appliance^

查詢或訂購 For enquiries or order placement:

產品銷售熱線 : 2232 1000
Sales Hotline

各煤氣客戶中心
Any Towngas Customer Centre

www.towngasappliance.com
f Towngas Appliance



^安裝電掣及煙窗需另收費。免費維修保養及送貨安裝服務只適用於住宅用戶，所有行使禁區的地區則不應提供維修保養及送貨安裝服務。香港中華煤氣有限公司不會為本公司產品因不當安裝、操作、濫用或錯誤使用等情況而引致的損壞提供三年免費更換零件保養服務。此保養服務並不包括損耗配件。新更換機件零件（不包括損耗配件）的保養期延長至24個月，規格如有更改，恕不另行通知。所有圖片只供參考。
^Charges for electric work and installation of flue box are not included. Free warranty, delivery and installation servicing only for residential customers. Warranty, delivery and installation servicing will not be provided for all restricted areas. The Hong Kong & China Gas Co., Ltd. will not provide the 3-year free spare parts replacement warranty service to any product damages resulting from improper installation, mishandling, abuse of use and misuse of our Company products. This warranty service does not cover consumable parts. Warranty of newly replaced spare parts (except consumable parts) of Towngas appliances is extended to 24 months. All specifications are subject to change without notice. All photos are for reference only.

© 版權所有。未獲本公司授權，不得翻印、複製或使用本單張作任何用途。
© All rights reserved Copying, reproducing or using the contents of this leaflet are not allowed without prior permission from Towngas.



RM/UBWH/0123



隱藏式熱水爐系列
Cabinet-concealed Water Heater Series



超薄型系列 Superslim Series


RJW15 / 20 SN (WM)



附送1個有線遙控器#
1 complimentary
wired remote control#

RJW15/20SN(WM)是銷售代號，GU05認可型號為RJW15/20SN
RJW15/20SN(WM) is a sales code, GU05 approved model is RJW15/20SN

RJW15 / 20 低位超薄型恆溫熱水爐安裝位 Low-level Temperature-modulated Superslim Water Installation



箱式系列 Box Type Series



TRJW162 / 222TFL 附送1個有線遙控器#
1 complimentary
wired remote control#


TRJW162 / 222TFQL* 附送1個有線遙控器#
1 complimentary
wired remote control#

TNJW161 / 221TFL 附送1個有線遙控器#
1 complimentary
wired remote control#

TNJW161 / 221TFQL* 附送1個有線遙控器#
1 complimentary
wired remote control#


TRJW162/222及TNJW161/221 低位箱式煤氣恆溫熱水爐安裝位

Low-level Box Type Temperature-modulated Water Heater Installation



TRJW162/222及TNJW161/221 高位箱式煤氣恆溫熱水爐安裝位

High-level Box Type Temperature-modulated Water Heater Installation




	A	B	C	D	E	F
TRJW162/222	370	453	280	120	≥100	≥703
TNJW161/221	360	480	265	195	≥150	≥780

箱式系列 Box Type Series




RBOX16L / QL 高位箱式煤氣恆溫熱水爐安裝位

High-level Box Type Temperature-modulated Water Heater Installation



RBOX16R / QR 高位箱式煤氣恆溫熱水爐安裝位

High-level Box Type Temperature-modulated Water Heater Installation



熱水爐安裝在閣層室內（如假天花），須提供通風設施（如百葉），以保持空間內通風良好。此外，假天花須可活動開啟並確保下方預留足夠空間供吊架下降以便檢修。
If the water heater is installed in a compartment (such as false ceiling), ventilation facilities (such as louvre) must be provided to keep the compartment well ventilated. In addition, the false ceiling should be removable and reserve sufficient space underneath to drop down the hanger for servicing.